

SANITOL BLEACH SACHETS

Hospital Grade Disinfectant



FEATURES

- 62% of available chlorine
- Long shelf-life
- Rapid disinfection
- Easy to use
- Convenient and stable source of chlorine
- Uniform rate of dissolving

AREAS OF USE

- Food processing facilities
- Restaurants & cafes
- Hospitals
- Aged care facilities

PRODUCT ENQUIRIES

Customer Service: 1800 334 679 jasolcsteam@gwf.com.au

For further information regarding product safety and handling, refer to the Safety Data Sheet and product label.

DESCRIPTION

SANITOL BLEACH SACHETS safely and simply provide a disinfecting agent for cleaning and sanitising purposes of hard surfaces. They contain 62% chlorine, which is one of the highest commercially available strength. SANITOL BLEACH SACHETS feature a long shelf life, showing minimal chlorine loss after more than one year of storage. It comes in an individual 8g sachet, which provides 100ppm of chlorine when diluted in 50L of water.

DIRECTIONS FOR USE

Dilute one sachet in 50L of water to achieve 100 ppm of chlorine.

Consult your Jasol representative for further information.

SAFETY INFORMATION

SANITOL BLEACH SACHETS are classified as Hazardous according to the GHS. SANITOL BLEACH SACHETS are classified as Dangerous Goods according to the ADG Code (7th

SANITOL BLEACH SACHETS are NOT a Scheduled Poison according to the SUSMP. Avoid contact with eyes and skin. Refer to SDS for further information.

FIRST AID INFORMATION

For advice in an emergency, contact Poisons Information Centre (Phone Australia 13 11 26) or a doctor at once. If swallowed do NOT induce vomiting. Wash mouth thoroughly with water and seek medical attention. If in eyes, hold eyelids apart and flood with water for at least 15 minutes. Seek immediate medical attention. If on skin, remove contaminated clothing and wash affected area with running water. Seek medical attention if irritation persists.

24 HOUR TOLL FREE EMERGENCY PHONE NO: 1800 629 953

PHYSICAL & CHEMICAL PROPERTIES

Solid Granules **FORM** COLOUR White **ODOUR** Chlorine

pН 6.0-7.0 (1% Solution)

AVAILABLE CHLORINE

FLAMMABILITY Not Combustible. Oxidiser



REFER OVERLEAF FOR ADDITIONAL INFORMATION





Providing hygiene service solutions since 1934

Printed version is Un-Controlled





SANITOL BLEACH SACHETS

Hospital Grade Disinfectant



EFFICACY

SANITOL BLEACH SACHETS were evaluated by the AOAC Hard Surface Carrier Test 991.47, 48, 49 (modified) at 8g/L w/v concentration & 10 minutes contact time in standard hard water.

The product passed the test against all prescribed organisms:

- Pseudomonas aeruginosa
- Staphylococcus aureus
- Salmonella choleraesuis



Providing hygiene service solutions since 1934